MY CHAIR™

PORTABLE BOOSTER AND ACTIVITY SEAT

Model 3510

Owner's Manual

READ ALL INSTRUCTIONS BEFORE ASSEMBLY AND USE OF CHAIR. **KEEP INSTRUCTIONS FOR FUTURE USE.**

Regalo International, LLC
14305 Southcross Drive
Suite 100
Burnsville, MN 55306
952-435-1080

" ⚠ **WARNING:** Prevent serious injury or death from falls or sliding out.
Failure to follow these warnings could result in serious injury or death.

-Be sure that BOOSTER SEAT is securely attached to adult chair before seating a child.
-Always secure child in the restraint until child is able to get in and out of the Booster Seat without help (about 2 1⁄2 years old).
-Never leave child unattended. Always keep child in view when in the BOOSTER SEAT.
-Check stability of the BOOSTER SEAT before and after seating child.
-Discontinue use if the BOOSTER SEAT is broken. Contact manufacturer immediately for replacement parts or service.
-Do not use without the anchoring strap that is used to secure the BOOSTER SEAT on to adult chair.
-Keep the BOOSTER SEAT and adult chair surface clean and try to prevent seat from slipping.
-Use only for a child capable of sitting upright unassisted.
-"DO NOT USE THIS BOOSTER SEAT UNLESS ALL 4 CORNERS OF THE BOOSTER SEAT ARE SECURELY POSITIONED ON THE SURFACE OF THE ADULT SEAT."
-Do not hang objects from the BOOSTER SEAT.
-Use only on adult seats that have a solid surface.

Diagram(1)

OPEN THE CHAIR FOLLOWING THE DIRECTION OF THE ARROWS.

Diagram(2)

AFTER UNFOLDING THE BOOSTER SEAT, IT SHOULD LOOK LIKE THE ABOVE DIAGRAM(2).

Diagram(3)

PLACE THE REMOVABLE SEAT LINER OVER THE BACK OF THE SEAT OF THE BOOSTER SEAT. THEN SECURE THE FRONT OF THE LINER WITH THE VELCO STRIP.

Diagram(4)

Diagram(5)

WRAP EACH END OF THE ANCHORING STRAP UNDERNEATH THE SEAT BOTTOM OF THE ADULT CHAIR AND FIRMLY CONNECT THE MALE AND FEMALE ENDS OF THE BUCKLE, THEN TIGHTEN BY PULLING THE LOOSE END OF THE STRAP UNTIL THE BOOSTERSEAT IS SECURELY ANCHORED TO THE ADULT CHAIR, AS SHOWN IN DIAGRAM (4), NEXT, CONNECT THE BACK STRAPS AROUND THE BACK SIDE OF THE ADULT CHAIR BY CONNECTING THE BUCKLES AS SHOWN IN DIAGRAM (5). ONCE CONNECTED, TIGHTEN THE STRAPS TO ENSURE THEY ARE SECURED.

*NOTE: AFTER TIGHTENING THE STRAP, MAKE SURE THE BOOSTER SEAT IS CENTRED ON THE ADULT CHAIR.

Diagram(6)

Fold the Booster Seat by pushing it towards the direction of the arrows.

HARNESS INSTRUCTIONS

To Secure your child in the harness, push buckle tongues (A) into buckle housing (B) and adjust with waist strap adjuster so that the waist strap is firmly secured around child.



CARE AND MAINTENANCE

Periodically check the My Chair for sign of damage, wear or for missing components. Do not use if any part is missing, worn or damaged. Always dry metal parts to avoid the the formation of rust.

FABRIC CARE

HAND WASH ONLY WITH DAMP CLOTH AND SOAP, AIR DRY

Regalo International, LLC
14305 Southcross Drive
Suite 100
Burnsville, MN 55306
952-435-1080

07/01/2010-V1